

THIS MANUAL IS AN ONLINE BACKUP TO YOUR
ORIGINAL HARDCOPY VERSION.

RX7CITY.COM ASSUMES NO RESPONSIBILITY IN HOW YOU USE
THIS MANUAL. THIS MANUAL IS FOR EXPERIENCED MECHANICS
AND IS TO BE USED AT YOUR OWN RISK!



PRE-DELIVERY INSPECTION AND SCHEDULED MAINTENANCE SERVICES

PRE-DELIVERY INSPECTION..... 0— 2
SCHEDULED MAINTENANCE SERVICES 0— 3

67U00X-001

0 PRE-DELIVERY INSPECTION

PRE-DELIVERY INSPECTION TABLE

EXTERIOR

INSPECT and **ADJUST**, if necessary, the following items to the specifications:

- Glass, exterior bright metal and paint for damage
- Wheel lug nuts
88—118 N·m (9—12 m·kg, 65—87 ft·lb)
- Tire pressures (Refer to section 12)
- All weather strips for damage and detachment
- Operation of hood release and lock
- Operation of fuel lid and rear glass hatch opener
- Door operation and alignment
- Headlight aim

INSTALL the following parts

- Wheel caps (if equipped)
- Outside rearview mirror(s)
- Front air deflector (if equipped)
- Convertible top (if equipped)

UNDER HOOD—ENGINE OFF

INSPECT and **ADJUST**, if necessary, the following items to the specifications:

- Fuel, coolant and hydraulic lines, fittings, connections and components for leaks
- Engine oil level
- Headlight cleaner fluid level (if equipped)
- Power steering fluid level (if equipped)
- Brake and clutch master cylinder fluid levels (if equipped)
- Windshield washer reservoir fluid level
- Radiator coolant level and specific gravity

Protection °C (°F)	Specific gravity at 20 °C (68°F)
-4 (25)	1.028
-16 (3)	1.054
-26 (-15)	1.066
-40 (-40)	1.078

- Tightness of water hose clamps (including heater hoses)
- Tightness of battery terminals
- Drive belt tensions
- Accelerator cable and linkage for free movement
- Sub-zero starting system and fluid level

CLEAN spark plugs

NOTE: Do not blast with sand or abrasive cleaning materials

INTERIOR

INSTALL the following parts:

- Rubber stopper for inside rearview mirror
- Fuse for accessories

CHECK the operations of the following items:

- Seat controls (sliding and reclining) and head rest
- Door locks
- Seat belts and warning system
- Ignition switch and steering lock
- All lights including warning and indicator lights and retractable headlight mechanism
- IC sound warning system
- Horn, wipers and washers (front and rear, if equipped)
- Radio and antenna (if equipped)
- Cigarette lighter and clock
- Remote control outside rearview mirror (if equipped)
- Power window (if equipped)
- Heater, defroster and air conditioner at various mode selections (if equipped)

- Sunroof (if equipped)
- Headlight cleaner (if equipped)
- Theft-deterrent system (if equipped)
- Convertible Top (if equipped)

INTERIOR (cont'd)

CHECK the following items:

- Presence of spare fuse
- Upholstery and interior finish

CHECK and **ADJUST**, if necessary, the following items:

- Operation and fit of windows
- Pedal height and free play of brake and clutch pedal

	Pedal height mm (in)	Free play mm (in)
Clutch pedal	220—225 (8.66—8.86)	0.6—3.0 (0.02—0.12)
Brake pedal	205—210 (8.07—8.27)	4—7 (0.16—0.28)

- Parking brake
4—5 noches/98 N (10 kg, 22 lb)

UNDER HOOD—ENGINE RUNNING AT OPERATING TEMPERATURE

CHECK the following items:

- By-pass air control system
- Automatic transmission fluid level
- Initial ignition timing
- Idle speed
- Setting of throttle sensor

NOTE: Engine must not be started to perform this item.

ON HOIST

CHECK the following items:

- Manual transmission oil level
- Rear axle oil level
- Underside fuel, coolant and hydraulic lines, fittings, connections and components for leaks
- Tires for cuts and bruises
- Steering linkage, suspension, exhaust system and all underside hardware for looseness or damage

ROAD TEST

CHECK the following items:

- Brake operation
- Clutch operation
- Steering control
- Operation of meters and gauges
- Squeaks, rattles or unusual noise
- Engine general performance (including turbo)
- Emergency locking retractors
- Cruise control system (if equipped)

AFTER ROAD TEST

- REMOVE seat and floor mat protective covers
- CHECK for necessary owner information materials, tools and spare tire in vehicle
- REMOVE identification color tape on directional tires

87U00X-001

SCHEDULED MAINTENANCE SERVICES

Follow the Schedule 1 (Normal Driving Condition) if you mainly operate your vehicle where none of the following conditions apply. Follow the Schedule 2 (Unique Driving Condition) if one or more of the items below apply:

- REPEATED SHORT DISTANCE DRIVING.
- DRIVING IN DUSTY CONDITION.
- DRIVING WITH EXTENDED USE OF BRAKES.
- DRIVING IN AREAS USING ROAD SALT OR OTHER CORROSIVE MATERIALS.
- DRIVING ON ROUGH AND/OR MUDDY ROADS.
- EXTENDED PERIODS OF IDLING AND/OR LOW SPEED OPERATION.
- DRIVING FOR A PROLONGED PERIOD IN COLD TEMPERATURE AND/OR EXTREMELY HUMID CLIMATES.

Schedule 1 (Normal Driving Condition)

MAINTENANCE INTERVALS	Number of months or miles (kilometers), whichever comes first						Service data and inspection point	Page			
	Months	7.5	15	22.5	30	37.5			45	52.5	60
MAINTENANCE OPERATION	2,000	7,500	15,000	22,500	30,000	37,500	45,000	52,500	60,000		
	(3,000)	(12,000)	(24,000)	(36,000)	(48,000)	(60,000)	(72,000)	(84,000)	(96,000)		

Engine

Drive belts (except air pump drive belt)					I													• Cracks or damage • Tension	1-7
Engine oil	Non-Turbo	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	• Oil pan capacity: 4.4 liters (4.7 US qt, 3.9 Imp qt)	2-5
	Turbo	Replace every 5,000 miles (8,000 km) or 5 months																	
Oil filter	Non-Turbo					R				R				R				• Oil filter capacity: 0.3 liters (0.32 US qt, 0.26 Imp qt)	2-7
	Turbo	R	Replace every 5,000 miles (8,000 km) or 5 months																

Air Conditioner System (If equipped)

Refrigerant	Inspect the refrigerant amount annually																		
Compressor	Inspect the operation annually																		

Air Cleaner

Air cleaner element									R											4A-53 4B-59
---------------------	--	--	--	--	--	--	--	--	---	--	--	--	--	--	--	--	--	--	--	----------------

Ignition System

Spark plugs																					5-31

• Plug gap 2.0 mm (0.08 in)	
• Recommended spark plugs	
	Leading Trailing
	SD 10A SD 11A
	NGK

0 SCHEDULED MAINTENANCE SERVICES

Schedule 1 (Normal Driving Condition)

MAINTENANCE INTERVALS	Number of months or miles (kilometers), whichever comes first											Service data and inspection point	Page
	Months	7.5	15	22.5	30	37.5	45	52.5	60				
	Miles (Km)	2,000 (3,000)	7,500 (12,000)	15,000 (24,000)	22,500 (36,000)	30,000 (48,000)	37,500 (60,000)	45,000 (72,000)	52,500 (84,000)	60,000 (96,000)			

Cooling System

Cooling system			I		I		I		I		I		I	• Hoses for cracks or wear • Coolant level	3-5
Engine coolant					R								R	• Coolant capacity: Turbo 8.7 liters (9.2 US qt, 7.7 Imp qt) Non-Turbo 7.3 liters (7.7 US qt, 6.4 Imp qt)	3-5

Fuel System

Idle speed	I		I ²		I ²		I ²		I ²		I ²		I	Idle speed: 750 ± 25 (A/T, N Range)	4A-77 4B-80
Fuel filter													R	—	4A-76 4B-79
Fuel lines					I ¹								I	• Fittings, connections and components for leaks	4A-76 4B-79

Electrical System

Engine oil level warning system			I		I		I		I		I		I	—	15A-39
Engine coolant level warning system					I		I		I		I		I	—	15A-42
Sub-zero starting assist system	Inspect the operation seasonally (sub-zero weather use only).												4A-87 4B-90		

Chassis and Body

Brake line hoses and connections			I		I		I		I		I		I	• Proper attachment and connections	11-5
Disc brakes			I		I		I		I		I		I	• Caliper Operation • Thickness of disc plate: minimum... 1 mm (0.04 in) • Thickness of pad: minimum... 1 mm (0.04 in) • Disc run out 1 mm (0.04 in)	11-27 11-32
Steering operations and linkage					I								I	• Free play: 5-20 mm (0.20-0.79 in) • Operation and looseness • Fluid leakage or oozing	10A-5 10B-5

Schedule 1 (Normal Driving Condition)

MAINTENANCE INTERVALS MAINTENANCE OPERATION	Number of months or miles (kilometers), whichever comes first										Service data and inspection point	Page
	Months	7.5	15	22.5	30	37.5	45	52.5	60			
	Miles (K.m)	7,500 (12,000)	15,000 (24,000)	22,500 (36,000)	30,000 (48,000)	37,500 (60,000)	45,000 (72,000)	52,500 (84,000)	60,000 (96,000)			

Chassis and Body

Front suspension ball joints					I						I	• Damage, looseness and grease leakage	13-11
Drive shaft dust boots					I						I	• For cracks, damage, leakage of grease or looseness of band	9-16
Exhaust system heat shield					I						I	• clearance to body, and exhaust system	4A-83 4B-86
Front wheel bearings					L						L		9-4
Manual transmission oil											R		7A-3
Rear axle oil											R		9-48
Bolts and nuts on chassis and body						T							
Toe control hub and control link					I						I		13-24 9-14

SCHEDULED 1 (NORMAL DRIVING CONDITION)

Chart symbols:

- I: Inspect, and if necessary correct, clean or replace
- R: Replace or change
- T: Tighten
- L: Lubricate

Remarks:

After 60 months or 60,000 miles (96,000 km), continue to follow the described maintenance items and intervals periodically. As for * marked items in this maintenance chart, please pay attention to the following points.

*1 This maintenance operation is recommended by Mazda. However, this maintenance is not necessary for emission warranty coverage or manufacturer recall liability.
 *2 This maintenance operation is required for Canada and all states except California. However we do recommend that this operation be performed on California vehicles as well.

0 SCHEDULED MAINTENANCE SERVICES

SCHEDULE 2 (UNIQUE DRIVING CONDITION)

Chart symbols:

- I: Inspect, and if necessary correct, clean or replace
- R: Replace or change
- T: Tighten
- L: Lubricate

Remarks:

After 60 months or 60,000 miles (96,000 km), continue to follow the described maintenance items and intervals periodically. As for * marked items in this maintenance chart please pay attention to the following points.

- *1 This maintenance operation is recommended by Mazda. However, this maintenance is not necessary for emission warranty coverage or manufacturer recall liability
- *2 This maintenance operation is required for Canada and all states except California. However we do recommend that this operation be performed on California vehicles as well.